



4700 Three Stage Torque Link

Item ID	Item Description	Qty Needed
2855	¼ " High Collar Lockwasher	3.00
2874	¼ -20x5/16 Nylon Tip Set Screw	1.00
4502	Plate, Spring Center	1.00
4507	Shaft Bushing	1.00
4508	Shaft Wiper	1.00
4510	O-ring Travel Indicator	2.00
4511	Washer Lg Dampener Bushing	4.00
4513	.75-16 R.H. Jam-Nut, Hex	2.00
4515	.31-18 Hex Flex Toplock Nut	3.00
4516	Stud Spring Adj. .31-18x3" L	3.00
4517	.31-18 Jam Nut	3.00
4520	.50-20 x 1"Bolt gr5 HHCS	2.00
4521	.44 Mega Thick Flat Washer	2.00
4524	.75-16 Nylock Jam Nut	2.00
4525	¼" x 8¾" Travel Indicator Rod	1.00
4526	¼ -20 X 7/8 SHCS	3.00
4527	.25-20 Top-Lock Hex Nut	3.00
4531	Grease Fitting	2.00
4532	Spacer	1.00
4535	Housing, Seal, Bushing Ass'y	2.00
.. 4504	Housing	2.00

Item ID	Item Description	Qty Needed
.. 4507	Shaft Bushing	2.00
.. 4508	Shaft Wiper	2.00
4539	Flange Nut .25-20	2.00
4541	.50 Lockwasher	2.00
4542	5/16 Split Lockwasher	3.00
4543	1/4-20 x 3/4 SHCS	3.00
4544	Plate, Spring Front	1.00
4545	Plate, Spring Rear	1.00
4563R	Poly Bushing , Red, 87A	1.00
4563Y	Poly Bushing, Yellow, 75A	2.00
4575	Bearing Housing Threaded	1.00
4576	Adjuster Nut (bearing housing)	1.00
4702	Brake Bushing Plate	1.00
4703	Spacer	1.00
5507	Stand Off Tube 8.25" L	3.00
5510	5/16-18 x 1" HCS	3.00
5601	Seal Washer	1.00
5608	Engine Shaft, 10.688 L	1.00
5609	Shaft 6.25" L Ass'y	1.00
6067	Washer	1.00

4/1/2010

4/1/2010