



## 4590 Secondary Spring Torque Link

Item ID	Item Description	Qty Needed	Item ID	Item Description	Qty Needed
2855	1/4 " High Collar Lockwasher	1.00	4535	Housing, Seal, Bushing Assy	1.00
2874	1/4 -20x5/16 Nylon Tip Alloy Ste	1.00	.. 4504	Housing	1.00
4502	Plate, Spring Center 7 GA	1.00	.. 4507	Shaft Bushing	1.00
4510	O-ring Travel Indicator 1/4"	1.00	.. 4508	Shaft Wiper	1.00
4511	Washer Lg Dampener Bushing	4.00	4539	Flange Nut .25-20	1.00
4513	.75-16 R.H. Jam-Nut, Hex	1.00	4541	.50 Lockwasher	1.00
4515	.31-18 Hex Flex Toplock Nut	3.00	4542	5/16 Split Lockwasher	3.00
4516	Stud Spring Adj. .31-18x3"	3.00	4543	1/4-20 x 3/4 SHCS	3.00
4517	.31-18 Jam Nut	3.00	4544	Plate, Spring Front	1.00
4519	5/16-18 x 3/4" HHCS Gr 8	3.00	4545	Plate, Spring Rear	1.00
4520	.50-20 x 1"Bolt gr5 HHCS	1.00	4560	Rear Rod End Attaching Plate	1.00
4521	.44 Mega Thick Flat Washer	1.00	4563R	Poly Bushing , Red, 87A	1.00
4524	.75-16 Nylock Jam Nut	1.00	4563Y	Poly Bushing, Yellow,75A	2.00
4525	1/4" x 8 3/4" Travel Indicator Rod	1.00	4575	Bearing Housing Threaded	1.00
4527	.25-20 Top-lock Hex Nut	1.00	4576	Adjuster Nut (Bearing housing)	1.00
4531	Grease Fitting	1.00	4506	Shaft	1.00
			4518	Stand Off Tube " L	3.00